4.3 Cat38XX switch staging at warehouse completed 13
4.4 Installation and Configuration at the School Campus:.....14
4.5 3850 S1 0 0 1 541.63 698.14 Tm 98.l347-17pus:hc( )kanhe School Campus:

2 G [( )] TJ ET Q q 0.00000912 0 612 792 re W* n BT /F1 11.04 Tf 1 0 04 T2.96 64 718.54 Tm86 [[(2 G [( )] TJ ET Q

Allow Dev Key = yes
Manual Boot = no
Enable Break = no

1.3 2960X Fan-less switch

IOS version: as specified in the LAN sheet. Below is an example:

IOS File: c2960x-universalk9-tar.152-2.E.tar
IOS File Directory: flash:/ c2960x-universalk9-tar.152-2.E/ c2960x-universalk9-tar.152-2.E.bin

2 4500X Switch hardware Installation and Configuration Procedures – Staging at the Warehouse

2.1 4500X Switch Hardware Information

1. **Parts and Part Numbers**

Parts	**Part Numbers**
Base systems	WS-C4500X-16SFP+ OR WS-C4500X-32SFP+
Expansion Module	C4KX-NM-8SFP+
Optics	SFP-10G-SR= : (For multimode connections to local campus switches) SFP-10G-LR: (For single mode connections to the GAATN metro fiber network)

Note: 10G SFP+ Twinax cables may use to connect the Aruba Con9i1(g 0 612 792 reW*n8 55.224 reW*nI

2.5 Load Startup Configuration and Configure the Switch

Note:

There will be TWO customized configuration files is provided by AISD.
The first one is a pre-config file consisting of a few commands that are intended to be copy-and-pasted directly from that file into the switch in global configuration mode. This pre-config file prepares the switch to be configured from the master config file.
The other one is the master configuration file, it will be copied to the startup configuration of the switch via USB flash or TFTP.

1) After rebooting, within the global configuration on the Cat4500X, store the AISD Asset Tag number in the "snmp contact" field:

```
c4X01(config)# snmp-server contact
```

2) On the Cat4500X, copy the running configuration to startup configuration.

2.6 4500X switch staging at warehouse completed - *Unofficial Checklist*

The below table is an Unofficial Checklist, to be performed after staged at warehouse

Action	**Command**	**Verification**	**OK?**
Check hardware configuration	**show module**	Ensure that appropriate modules are all in correct slots, and all show "**Status: OK**"	
Check for POST failures	**show log**	Ensure that no hardware failures are reported	
Check IOS	**show version**	boot image should be on slot0 and bootblash.	
Check that pre-config file was copied and pasted successfully	**show vtp status** **show vlan** **show crypto key mypubkey rsa**	VTP domain should be set, mode should be transparent, VLANs in the 300s, 501 and 600s should be configured A crypto key should be displayed in the output	
Check that master config file was copied successfully			

2.8 Test and verify the correct power cord connection of the 4500X

Unplug one of the power cords, then check the switch with the following command, make sure the command output has indicate the DOWN power supply with a Status BAD

```
188c4X01#sh env | be Power
Power          Fan        Inline
Supply  Model No
```

8) “**Show switch**

The other one is the master configuration file, it will be copied to the startup configuration of the switch via USB flash or TFTP. **Don't copy-and-paste the master config to the switch!**

A. Copy the appropriate pre-config file to the switch stack

1) Load the appropriate pre-config file titled <switch-num><closet>38<num>_pre.cfg (e.g. 252A3801_pre.cfg) into a text editor.
2) Select all the text in the file and copy it to the clipboard
3) Enter enable mode on the switch and paste the clipboard contents in. This will set up the switch member priorities, vtp information, and create a crypto key.

B. Load the master configuration files to start-up configuration of the switch stack

c. Via USB flash – recommended method

1) Copy the master configuration file to your USB flash.
2) Insert the USB flash to the Active Switch Member USB port
3) After console in the switch stack, check the directory name of the flash, and copy the master configuration file of the flash directory to the start-up configuration. Below is an example of the USB directory usbflash0: and the master configuration file is 252A3801.cfg

(1) While the stack is powered off, install the C3850-NM-2-10G switch modules in the first and last switch in the stack. These should have been tagged/identified earlier in an earlier step. *However, switches reach the campus, as the SFPs are easy to damage in transit.*
(2) Power the whole Switch Stack back on by reconnecting all the power cables
(3) Switch labeling: While the stack is booting up, label each of the switches as xyzA38mn-N, where "N" is the switch member number of the stack, and "xyzA38mn" is the hostname for the stack. See AISD Label standard for detail. The switch numbers should have been tagged/identified earlier in an earlier step.
(4) Asset tag placement: according to AISD specs.
(5) Label the power cables according to AISD specs.
(6) After the switch stack is back online, it should be fully configured, and there should be no need to remove any parts of the configuration.
(7) Start a new console session. Within the global configuration on the Cat3850, store the AISD Asset Tag number in the "snmp contact" field:
XYZA3801(config)# **snmp-server contact** [#1-AssetTag,2-AssetTag…6-AssetTag,#]
List all the switch member asset tag numbers to [#1-AssetTag,2-AssetTag…6-AssetTag,#].eg, a stack has two members, switch 1 asset tag is 4646464, switch 2 asset tag is 5757575, the command will be **snmp-server contact 1-4646464,2-5757575**

(8) Copy the running configuration to startup configuration:
"**copy run start**" <or> "**wr mem**"

4.3 Cat38XX switch staging at warehouse completed - *Unofficial Checklist*

(official checklist is performed and captured at Campus)

Action	Command	Verification	OK?
Check hardware configuration	**Show switch detail**	Ensure that all appropriate switches are present, and all stack ports show "**Status: OK**"	
Check for POST failures	**show log**	Ensure that no hardware failures are reported	
Check IOS – INSTALL MODE	**1) show version** **2) sh ver | inc INSTALL** 3) **show boot system**	IOS version should be the same as stated in the LAN install sheet. Image is installed with "INSTALL" mode. System image file is "flash:packages.conf"	
Check that pre-config file was copied and pasted successfully	**1) show vtp status** **2) show vlan** **3) show crypto key mypubkey rsa**	VTP domain should be set, mode should be transparent, VLANs in the 300s, 501 and 600s should be configured A crypto k9 Tm>2.41 214.63 63.144 f1197.3	

According to AISD WAN Network Labeling Standard.docx

4. Load Startup Configuration and Configure the Switch

Note:

There will be TWO customized configuration files is provided by AISD.

The first one is a pre-config file consisting of a few commands that are intended to be copy-and-